

Mach3 USB Motion Board NPN Installation Manual


Doc Ver: 2.1



Features:

- ✧ USB Full-speed connection.
- ✧ Up to 5 axes, 500kHz pulsing engine, which is suitable for the servo or stepping motor. Any axis can be configured as a Step/Dir Spindle.
- ✧ Support slave axis (dual side motor drive: dual X/Y/Z), support home automatic leveling (dual side home switch).
- ✧ 2 real-time Manual Pulse Generation (MPG) input ports for 2 MPG at the same time. When the MACH3 MPG is set in the multi-step mode, it has the same real-time performance as the CNC machining center, smoothly. The control board has no delay and the mechanical system performance is fully utilized.
- ✧ 16 general-purpose input, with particular indicators, the input signal states can clearly shows.
- ✧ 7 general-purpose output, It can be configured as: spindle clockwise / CCW / Mist / Flood / VB script programming control.
- ✧ PWM output*1 channel, 0-10V analog voltage output*1 channel, 0-5V analog voltage output*1 channel. 3 outputs channels are used for spindle motor speed adjustment: PWM pulse width / 0-10V or 0-5V inverter.
- ✧ 2 analog input ports for adjusting the machining speed / jog speed / spindle speed.
- ✧ Status indicator LED can be useful to show the USB connection, and working status by flashing.
- ✧ 5 high-speed optocouplers (Dual Channel) with 10MHz, 25 general optocouplers for isolating all of the input/output signals, this high-cost

design can be provided high performance and stable system.

- ✧ Fully supporting all Mach3 versions. Supporting Windows series, including Windows XP-Windows10(32bit/64bit).
 - ✧ No need to install any USB drivers, it can be used after plugging in the computer.
 - ✧ Easy firmware update.
- 



Contents

[Revisions List](#)

[Basic connection diagram \(Overview\)](#)

[Mechanical dimensions diagram](#)

1 [Prepare](#)

1.1 [Mach3 download and install](#)

1.2 [Download and install the Mach3 plugin](#)

1.3 [Status indicator\(LED\) of motion control board, External power supply, Grounding](#)

2 [Motion control board and PC connection](#)

2.1 [USB](#)

3 [Firmware upgrade, Restore factory firmware, Reset](#)

4 [Electrical characteristics and wiring table](#)

5 [Wiring and configuration with stepper \(or servo\) drives](#)

5.1 [5-axis outputs interface schematic](#)

5.2 [Stepper/Servo Driver Wiring Diagram](#)

5.3 [Motor parameter configuration](#)

5.4 [Pulse Spindle Configuration](#)

6 [Digital input](#)

6.1 [NPN input interface characteristics, wiring and configuration](#)

6.2 [NPN MPG\(Manual Pulse Generation\) wiring](#)

6.3 [Wiring of MPG switch](#)

6.4 [Configuration of the MPG](#)


- 6.5 [Probe\(Auto Tool Zero\) wiring and configuration](#)
- 6.6 [Wiring and configuration of spindle speed measurement signal input](#)
- 7 [Digital output](#)
 - 7.1 [Interface characteristics of general digital output](#)
 - 7.2 [Wiring diagram](#)
 - 7.3 [Configuration](#)
- 8 [Spindle speed control analog PWM output](#)
 - 8.1 [Interface Characteristics of PWM Output](#)
 - 8.2 [Spindle Governor Wiring](#)
 - 8.3 [Configuration](#)
- 9 [Spindle speed control analog voltage output](#)
 - 9.1 [Interface Characteristics of voltage Output 0-10V/0-5V](#)
 - 9.2 [Spindle Inverter Wiring](#)
 - 9.3 [Configuration](#)
- 10 [Slave axis \(dual side motor drive: dual X/Y/Z\)](#)
 - 10.1 [Slave axis configuration](#)
 - 10.2 [Single home switch configuration](#)
 - 10.3 [Dual home switch \(automatic leveling\) configuration](#)
- 11 [External Adjustment Knob](#)
 - 11.1 [Interface characteristics of analog input](#)
 - 11.2 [Wiring diagram](#)
 - 11.3 [Configuration](#)



Revisions List

Date/Version	Info
2021-1-5 Ver2.0.0	MODEL: LF77-AKZ250-USB3-NPN(B)
2021-2-1 Ver2.0.1	Revised document
2021-4-27 Ver2.0.2	Added: MPG Enable Button wiring and description
20.1-8-2 Ver2.1	(1)Add slave axis , support home automatic leveling (dual-side home switch) (2)Add Axis-Link Configuration dialog, Pulse(Step/Dir) spindle configuration

Basic connection diagram (Overview)




1. Prepare

1.1 Mach3 download and install




The latest version of Mach3 official website download URL: <https://www.machsupport.com/>

After entering the official website, click DOWNLOADS & UPDATES => MAIN PROGRAMS as shown in the blue circle below



After entering the download page, find MACH3 and download it, as shown in the blue circle below.






Mach3Versio
n3.043.exe

After the download is complete, install Mach3



Note:

The Parallel Port Driver does not require.





1.2 Download and install the Mach3 plugin



In order to enable MACH3 to recognize and drive this motion control board, you need to install a mach3 plugin.

Copy or drag **eMotionMach3.dll** (Unzip the eMotionMach3.zip) into **Mach3\PlugIns** folder.

For example, if your Mach3 software is installed in C:\Mach3, place eMotionMach3.dll into **C:\Mach3\PlugIns**



Mach3 Plugin eMotionMach3.zip

Please go to the following URL to download the latest version.

<http://www.dappr.com>




Mach3Mill After completing the Mach3 plugin installation, start the Mach3 software.

A dialogue of "Motion Control Hardware PlugIn sensed!!" is shown.

Please choose the option "USB.Ethernet-Motion-board".


You can also check "Don't ask me this again".



1.3 Status indicator(LED) of motion control board, External power supply

1.3.1 The motion board has a status indicator LED that indicates the current status by different blinking modes.


LED flashing mode	Status
Always bright	Standby (POWER ON)
Slow flashing	Connection (has already established a connection with MACH3 via USB)
Fast flashing	5-axis operation (eg running G code, jog, but not pulse spindle)
Slow flashing, gradually flashing quickly, turn off after 5 seconds	After pressing the RECOVERY button for 5 seconds, the Motion Board soft reset.



1.3.2 External power supply



1.3.2.1 Schematic





1.3.2.2 Wiring


Motion control board, requiring DC12V-24V (0.3A) power supply



Warning: The control panel input voltage (peak) cannot exceed 26V.

The board requires an **independent power supply** (control system power supply) that can be shared with sensors, handwheels, and the like.

Because the motor has a back EMF, the control board **cannot share a power supply with the motor** to ensure safety and reliability.



2. Motion control board and PC connection



Note:

First: complete the [Mach3 plugin installation](#), start Mach3 and [select the external motion control board](#)



2.1 USB

Magnet ring installed in the USB cable at both ends




Attention:


Please use the USB cable supplied with this product.

If you choose the USB cable yourself, please make sure to use a quality cable.

The motion control board is connected to the PC using a USB cable and is [powered on \(DC12V-24V\)](#)




This motion board does not need install any USB driver, Windows XP - Windows 10 can directly identify



Start Mach3 and [select external motion control board](#).

(1)Right click on the CNC icon, pop up the settings dialog, (2)select "USB", (3)press OK to save the settings.




When the Mach3 is successfully connected to the motion control board (USB), the STATUS-LED indicator flashes slowly.

3. Firmware upgrade, Restore factory firmware, Restore factory settings



The chip firmware of this motion control board supports upgrades, and users can continuously get the latest feature support. The firmware is stored in the Mach3 plugin (the latest version of the Mach3 plugin, please download it from <http://dappra.com>). When Mach3 is launched and connected to the motion control board, the firmware version is checked and automatically upgraded.




Normally, the upgrade can be completed successfully. If the upgrade fails in a special situation and the board fails to start, the motion board provides the function of **restoring the factory firmware**. The steps are as follows:

- i. Unplug the USB plug from the Motion Control Board
- ii. Press and hold the RECOVERY button of the Motion Control Board
- iii. Plug in the USB plug to the Motion Control Board (and make sure the other end of the USB cable is plugged into the PC)
- iv. Release the RECOVERY button
- v. The STATUS LED is always on (standby status), indicating that the recovery operation is complete (It takes about a few seconds)



SOFT RESET Motion Control Board, the steps are as follows:


- i. The USB plug is plugged into the Motion Control Board (and the other end of the USB cable is plugged into the PC), and the STATUS-LED is on.
- ii. Press and hold the RECOVERY button for more than 5 seconds, STATUS-LED flashes slowly => fast flashing => off
- iii. Release the RECOVERY button, the STATUS-LED is always on (standby), SOFT RESET completed.



HARD RESET Motion Control Board, the steps are as follows:

- i. Unplug the USB plug from the Motion Control Board.
- ii. Plug in the USB plug to the Motion Control Board (and make sure the other end of the USB cable is plugged into the PC)

4. Electrical characteristics and wiring table



4.1 Power Input

Connector	FUNCTIONS	ELECTRICAL	Description
0V	power input negative	0V	Common ground: (axis/digital input/digital output/PWM)
24V	power input positive	DC12V-24V / 0.3A	Independent power supply required (separate from motor)

4.2 Power Output

The Motion board has a 5V output power supply for the interface of the 6 stepper drives and the PNP-5V MPG 2.

Connector	FUNCTIONS	ELECTRICAL	Description
5V	power output positive	DC5V / 500mA	All 5V Connectors, a total output of 500mA

4.3 (NPN) Port 1 Digital Input x16 / Speed measurement /MPG 1/MPG 2

Connector	FUNCTIONS	ELECTRICAL	Description
1	Digital Input Pin 1	NPN Optocoupler isolation x16 Interface voltage = power input (12V-24V) Min trigger current: 3mA Max operating current (12V): 5mA Max operating current (24V): 9mA	Port 1 Digital Input Speed measurement MPG 1 Input MPG 2 Input
	Speed measurement		
2	Digital Input Pin 2		
3	Digital Input Pin 3		
4	Digital Input Pin 4		
5	Digital Input Pin 5		
6	Digital Input Pin 6		
	MPG 2 Input A		
7	Digital Input Pin 7		
	MPG2 Input B		
8	Digital Input Pin 8		
9	Digital Input Pin 9		
10	Digital Input Pin 10		
11	Digital Input Pin 11		
12	Digital Input Pin 12		
13	Digital Input Pin 13		
14	Digital Input Pin 14		
15	Digital Input Pin 15		
	MPG 1 Input A		
16	Digital Input Pin 16		
	MPG 1 Input B		

4.4 Analog Input x2

Analog input for external potentiometer control speed, electrical characteristics are **non-isolated**

Connector	FUNCTIONS	ELECTRICAL	Description
AIN1	Analog Input Port 1	Non-isolated x2 Input voltage: 0V-3.3V Input current: <0.1mA	For external speed control: Spindle speed / jog speed / Feed
AIN2	Analog Input Port 2		

4.5 Axis Output x5

Connector	FUNCTIONS	ELECTRICAL	Description
XD (Xdir)	Xaxis Direction signal	High speed optocoupler isolation x10 Max: 24V / 13mA OC=Open collector output	Used to connect: Stepper drive server Driver
XS (Xstep)	Xaxis Step signal		
YD (Ydir)	Yaxis Direction signal		
YS (Ystep)	Yaxis Step signal		
ZD (Zdir)	Zaxis Direction signal		
ZS (Zstep)	Zaxis Step signal		
AD (Adir)	Aaxis Direction signal		
AS (Astep)	Aaxis Step signal		
BD (Bdir)	Baxis Direction signal		
BS (Bstep)	Baxis Step signal		

4.6 (OC) Port 1 Digital Output x7

Connector	FUNCTIONS	ELECTRICAL	Description
1	Digital Output Pin 1	Optocoupler isolation x7 Max: 24V / 500mA OC=Open collector output	Digital output pin for driving inductive loads (eg relay / solenoid valve) In order to prevent the back EMF from breaking through the driver chip (TBD62083), need an external independent freewheeling diode
2	Digital Output Pin 2		
3	Digital Output Pin 3		
4	Digital Output Pin 4		
5	Digital Output Pin 5		
6	Digital Output Pin 6		
7	Digital Output Pin 7		

4.7 Spindle Speed control signal output


Connector	FUNCTIONS	ELECTRICAL	Description
PWM	PWM (Pulse-Width Modulation) output	Optocoupler isolation x1 Max: 24V / 10mA OC=Open collector output	Spindle speed control signal output When using A10V, 24V power supply (>14V) is recommended for the control board
A10V	0-10V analog output	Optocoupler isolation x1 0-10V / 10mA(max)	
A5V	0-5V analog output	Optocoupler isolation x1 0-5V / 10mA(max)	

5. Wiring and configuration with stepper (or servo) drives



5.1 5-axis outputs interface schematic

6 axis output of the control board (10 channels): open collector output, high speed optocoupler isolation



5.2 Stepper/Servo Driver Wiring Diagram

The interface of the stepper/servo drive uses the following two power supply methods:


- Internal power supply 5V (suitable for stepper drive)
- External power supply 5V-24V (suitable for servo drive)




Note:

External power supply 12V-24V, this power supply can also supply power to the control board at the same time (share one control system power supply)

5.2.1 Use the 5V power supply inside the motion control board, suitable for stepper drivers, please install suitable current limiting resistors as needed.



5.2.2 Use 5V-24V external power supply, suitable for servo drive, please install suitable current limiting resistor as needed.



5.3 Motor parameter configuration

5.3.1 Mach3's X,Y,Z,A,B,C axis configuration, as shown below: (Config => Ports and Pins => Motor Outputs)

Signal	Enabled	Step Pin#	Dir Pin#	Dir Low...	Step Lo...	Step Port	Dir Port
X Axis	✓	0	0	✓	✓	0	0
Y Axis	✓	0	0	✓	✓	0	0
Z Axis	✓	0	0	✓	✓	0	0
A Axis	✓	0	0	✓	✓	0	0
B Axis	✓	0	0	✓	✓	0	0
C Axis	✗	0	0	✓	✓	0	0
Spindle	✓	0	0	✓	✓	0	0

5.3.2 Mach3 tuning setup as shown below: (Config => Motor Tuning)

X - AXIS MOTOR MOVEMENT PROFILE

Velocity mm's per Minute

Time in Seconds

Axis Selection: X Axis, Y Axis, Z Axis, A Axis, B Axis, C Axis, Spindle

Max Velocity: 1000
Max Acceleration: 100
G's: 0.050988
Step Pulse: 5
Dir Pulse: 5

Steps per:

Mach3 steps per unit = Mach3 steps per rev x Motor revs per unit

Please refer to: [Mach3Mill_Install_Config.pdf](#)

5.3.3 Mach3's axis running direction is recommended as shown below:

Mach3 Main menu => Config => Homing/Limits

Range of softlimits

If "V", then the axis DROs will be set to the Reference/Home Switch location values defined in the Home Off.

Axis	Reversed	Soft Max	Soft Min	Slow ...	Home ...	Home Neg	Auto	Speed %
X	X	100.00	-100.00	1.00	0.0000	X	V	20
Y	V	100.00	-100.00	1.00	0.0000	X	V	20
Z	V	100.00	-100.00	1.00	0.0000	X	V	20
A	X	100.00	-100.00	1.00	0.0000	X	V	20
B	X	100.00	-100.00	1.00	0.0000	X	V	20
C	X	100.00	-100.00	1.00	0.0000	X	V	20

Board ports, Axis direction: Depends on "√" or "X"

Ignore

The HOME direction setting of the axis: According to actual needs, hit "√" or "X"

HOME speed setting: percentage %

OK

5.4 Pulse Spindle Configuration. (Requires plug-in version 2.0.0.0 or above, [download the latest version](#))

5.4.1 You can set any axis of the motion control board as the pulse spindle output, and specify the B axis as an example: (1) Right click on the CNC icon, pop up the settings dialog. (2) Switch to the "Axis Link" page. (3) Select "Spindle" for "B-Board(BS/BD)". (4) Press OK to save the settings.

Xu Lifeng Motion Board Config (Plugin Version: 2.0.0.0)

Basic Axis Link 2

Plug-in Version

BOARD MACH3

X-Board (XS/XD)= X-Mach3 X 10.0000

Y-Board (YS/YD)= Y-Mach3 Y 0.0000

Z-Board (ZS/ZD)= Z-Mach3 Z 0.0000

A-Board (AS/AD)= A-Mach3 A 441.6471

B-Board (BS/BD)= Spindle B 0.0000

C-Board (CS/CD)= C-Mach3 C 0.0000

Default Spindle

Spindle (Parameters shown here are read-only)

Velocity Acceleration

Steps per Revolution per minute Revolutions/sec/sec

3200 600 50

Parameter setting:

[Mach3 Menu]Config > Motor tuning > [Button]Spindle > SAVE AXIS SETTINGS > OK

1


4 Save the settings

OK Cancel

1


5.4.2 Confirm that the spindle function (Spindle) is turned on, as shown in the figure below:

(Config => Ports and Pins => Motor Outputs)




Spindle "✓":
turn on the Mach3 spindle function

5.4.3 Motor operating parameter setting of Spindle, as shown below: (Config => Motor Tuning)




Steps per:
Motor Steps Per Revolution

5.4.4 The spindle is set to: Step / direction motor (Config => Ports and Pins=>Spindle Setup)



5.4.5 The direction of rotation of the pulse spindle is recommended as shown in the following figure:
Mach3 main menu => Config => Homing/Limits



Note:
Spindle maximum speed (pulleys) setting, refer to this manual: [Mach3 Menu "Config=>Spindle Pulleys.."](#)
Spindle Running test (the speed must be set before starting the spindle), refer to this manual: [Spindle test](#)


6. Digital input

6.1 NPN input interface characteristics, wiring and configuration




6.1.1 Interface schematic

Port **1** Digital Input: **NPN** Input x16, optocoupler isolation




6.1.2 Wiring

6.1.2.1 Button, mechanical switch wiring



6.1.2.2 NPN sensor wiring



6.1.3 Mach3 input signal configuration (Config => Ports and Pins=>Input Signals)


Encoder/MPG's		Spindle Setup			Mill Options	
Port Setup and Axis Selection		Motor Outputs		Input Signals	Output Signals	
Signal	Enabled	Port #	Pin Number	Active Low	Emulated	HotKey
	✔	1	10	✔	✘	0

- Tick "✔" to enable
- Port **1**
- According to the actual wiring, Type **1 - 16**
- NPN sensor is set to "✔" (0V = active low)



6.2 NPN MPG(Manual Pulse Generation) wiring


Output type of NPN MPG: **Open collector output (OC)**



Usually the MPG rotates clockwise, the coordinates increase; counterclockwise rotation, the coordinates decrease.

If the direction of rotation of the electronic handwheel is opposite to the direction of the MACH3 coordinate, exchange the wiring of the electronic handwheels "A" and "B".

6.3 Wiring of MPG switch



"Switch" and "Emergency Stop button" are connected to any input pin and then configured in Mach3.



When the "Enable Button" is pressed, the Jog Mode of Mach3 automatically switches to MPG mode, and automatically switches back to the original mode when the button is released.



The "Enable Button" automatically switches the JOG mode. The control board plug-in v1.3.1.2 (or later) version is required. See ["Download and install the Mach3 plugin"](#) to download the latest version.



If the "Enable Button" is not needed, please short-circuit it (the common terminal "COM" of the switches is directly connected to the "0V" terminal of the control board).



Attention:

"Emergency-Stop button" It is recommended to use the "normally closed" contact. If a fault occurs in the disconnection of the wiring, an emergency stop will be triggered.



6.4 Configuration of the MPG

6.4.1 Mach3 MPG configuration, as shown below: (Config => Ports and Pins => Encoder/MPG's)

Signal	Enabled	A -Port #	A -Pin #	B -Port #	B -Pin #	Counts...	Velocity
Encoder1	<input checked="" type="checkbox"/>	0				000000	100.00...
Encoder4	<input checked="" type="checkbox"/>	0				000000	100.00...
MPG #1	<input checked="" type="checkbox"/>	1		0	0	4.000000	100.00...
MPG #2	<input checked="" type="checkbox"/>	2		0	0	4.000000	100.00...
MPG #3	<input checked="" type="checkbox"/>	0		0	0		100.00...

In Mach3, press the keyboard "TAB" and set it as shown below.




Multi-Step mode, MPG signal is processed in real time by motion control board

Mach3's MPG Count does not change at this time.


	Abs Coords	Velocity	Count
MPG 1		+0.00	+0.00
MPG 2		+0.00	+0.00
MPG 3		+0.00	+0.00

- 💡 MPG Velocity: mouse click, type number, press Enter
- Jog Step: setup by click "Cycle Jog Step" button, or key in
- Click "Jog Mode" button, set the jog to "MPG" mode
- Click "Alt-A" button, select the axis(XYZAB) controlled by MPG 1
- Click "Alt-B" button, select the axis(XYZAB) controlled by MPG 2

6.4.2 Mach3 electronic MPG switch configuration, as shown below: (Config => Ports and Pins=>Input Signals)



Configure the functions performed by "OEM Trig" as shown below: (Config => System Hotkeys)





Mach3 axis selection for MPG / Jog step select OEM Buttons code table

Function	OEMCode
Select X for MPG 1	185
Select Y for MPG 1	186
Select Z for MPG 1	187
Select A for MPG 1	188
Select B for MPG 1	189
Select C for MPG 1	190
Select Jog Increment 1	191
Select Jog Increment 2	192
Select Jog Increment 3	193



Complete OEM Buttons code table, please search online

6.4.3 Mach3's emergency-stop button configuration, as shown below: (Config => Ports and Pins => Input Signals)

Engine Configuration... Ports & Pins

Encoder/MPG's | Spindle Setup | Mill Options

Port Setup and Axis Selection | Motor Outputs | **Input Signals** | Output Signals

Signal	Enabled	Port #	Pin Number	Active Low	Emulated	HotKey
EStop	<input checked="" type="checkbox"/>	1	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
Throttle On	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
OEM Trig #3	<input checked="" type="checkbox"/>	1	3	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
OEM Trig #4	<input checked="" type="checkbox"/>	1	4	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
OEM Trig #5	<input checked="" type="checkbox"/>	1	5	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
OEM Trig #6	<input checked="" type="checkbox"/>	1	6	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0

Pins 10-13 and 15 are inputs. Only these 5 pin numbers may be

Automated Setup of Inputs

确定 取消 应用(A)

Callouts:

- "EStop" Emergency-button
- Port 1
- According to the actual wiring, Type 1 - 16
- Set to "X" (Emergency-stop is normally closed button = active high)



Attention:


"Emergency-stop button" It is recommended to use the "normally closed" contact. If a fault occurs in the disconnection of the wiring, an emergency stop will be triggered.



When there is an external emergency stop signal input, the Mach3 RESET button cannot be turned off. Therefore, when testing, use a wire to temporarily short the 10#(Mach3 default) input point and 0V. And the board must have an external power supply (12V-24V) for Input / Output.

6.5 Probe (Auto Tool Zero) wiring and configuration

6.5.1 Wiring: Use digital input port **1**, any pin(1-16), as the Probe input signal



6.5.2 Mach3 Probe input signal configuration, as shown below: (Config => Ports and Pins=>Input Signals)

Encoder/MPG's			Spindle Setup			Mill Options	
Port Setup and Axis Selection			Motor Outputs		Input Signals		Output Signals
Signal	Enabled	Port #	Pin Number	Active Low	Emulated	HotKey	
Probe	<input checked="" type="checkbox"/>	1	12	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0	
Index	<input checked="" type="checkbox"/>	1	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0	

Tick "✓" Enable Probe Input

Port **1**


According to the actual wiring, Type 1 - 16

Tick "✓" (0V = active low)


6.5.3 Mach3's "auto tool zero" button, loading VB code

Mach3 can customize the function of some existing buttons on the screen, such as the "Auto Tool Zero" button, set the VB script.


6.5.3.1 Mach3 menu (Operator => Edit Button Script)



6.5.3.2 Click the "Auto Tool Zero" button in the flashing




6.5.3.3 Pop up the VB editor and delete the code




6.5.3.4 Enter the VB script in the VB editor

The VB "Auto Tool Zero" demonstration script "ProbeZ.txt" is provided in eMotionMach3.zip attached to the motion control card. Please open it with Notepad.



Copy the script from Notepad to the Mach3 VB Editor



6.5.3.5. Test: Click the "Auto Tool Zero" button **Auto Tool Zero** to test the tool zero action.




The VB "Auto Tool Zero" demonstration script "ProbeZ.txt", can be changed according to actual needs.

6.6 Wiring and configuration of spindle speed measurement signal input




6.6.1 Wiring: Speed measurement signal input fixed wiring at Pin 1 of digital input port 1.


6.8.1.1 External power supply, wiring of NPN sensor speed signal:



6.8.1.2 The equivalent circuit of the Hall device "44E" and the **NPN** sensor:




6.6.1.3 Example: Hall sensor model "44E" test wiring diagram



Hall sensor / Rotation plate installation diagram

Note: The magnet has a SN pole and should be adjusted during installation.





6.6.2 Mach3 measurement speed configuration

Start Mach3 and [select the external motion board](#), right click on the CNC icon, type the "Number of Pulses" in the settings dialog box, press OK to save the settings.

One revolution per spindle,
Sensor pulse number:
Range: 1-65535

RPM: The measured speed will be displayed in Mach3

Mach3 measures the speed signal configuration as shown below: (Config => Ports and Pins=>Input Signals)

Signal	Enabled	Port #	Pin Number	Active Low	Emulated	HotKey
Input #1	<input checked="" type="checkbox"/>	1	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
Input #2	<input checked="" type="checkbox"/>	1	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
Input #3	<input checked="" type="checkbox"/>	1	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
Input #4	<input checked="" type="checkbox"/>	1	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
Probe	<input checked="" type="checkbox"/>	1	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
Index	<input checked="" type="checkbox"/>	1	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
Limit Ovrd	<input checked="" type="checkbox"/>	1	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
EStop	<input checked="" type="checkbox"/>	1	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
THC O	<input checked="" type="checkbox"/>	0	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
THC U	<input checked="" type="checkbox"/>	0	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0

Index: Tick "V" Enable Measures speed


Ignore

7. Digital output




7.1 Interface characteristics of general digital output

Port **1** Digital Output: **OC**(Open collector) output x7, optocoupler isolation.




7.2 Wiring diagram

7.2.1 Driving resistive load



7.2.2 Driving inductive loads (such as relays, solenoid valves): installing an external freewheeling diode



7.3 Mach3 output signal configuration, as shown below: (Config => Ports and Pins => Output Signals)


Signal	Enabled	Port #	Pin Number	Active
Output #1	✓	1	1	✓
Output #2	✓	1	2	✓

8. Spindle speed control analog PWM output




8.1 Interface Characteristics of PWM Output

PWM (Pulse Width Modulation) output: **OC**(Open collector) output x1, optocoupler isolation.



8.2 Spindle Governor Wiring





8.3 Configuration

8.3.1 Mach3's Spindle configuration, as shown below: (Config => Ports and Pins=> Spindle Setup)

Tick "Use Spindle Motor Output" and "PWM Control", type the required frequency in "PWMBase Freq.", the unit is Hz.

Spindle Relay Control:
Type "1"- "20"
The configuration in the figure is:
M3: "Output #1"
M4: "Output #2"

Motor Control:
Tick "✓" as shown
PWMBase Freq. 4166
According to the needs of the governor, set the allowable range of Mach3: **5 - 4166**

Output Signals:
Output #1
Output #2

Output signal configuration "Output Signals", Set the corresponding "Output #1—Output #20"

8.3.2 Spindle relay configuration, as shown below: (Config => Ports and Pins=>Output Signals)

Signal	Enabled	Port #	Pin Number	Active Low
Output #1	✓	1	1	✓
Output #2	✓	1	2	✓


Tick "✓" when needed
Output #1
Output #2

Port 1


According to the actual wiring, Type 1 - 7

Tick "✓" (active low output)

8.3.3 The phase configuration of the spindle speed control signal PWM is shown in the figure below: (Config => Ports and Pins => Motor Outputs)



8.3.4 Mach3 menu "Config => Spindle Pulleys.", "Pulley Selection"




8.3.5 For other configurations of the spindle, please refer to "Mach3Mill_Install_Config.pdf"

8.3.6 Spindle test

In Diagnostics (Alt-7) or MDI(Alt-2):

- Keyboard input "M3".
- Keyboard input "S10000", spindle starts to rotate. (When testing, it is recommended to use half of the maximum speed to avoid the phase setting error and the spindle does not rotate. After the spindle is running, adjust the speed. Adjust the [spindle phase setting](#) when the spindle speed is opposite to the set speed)
- Keyboard input "M5", the spindle will stop rotating.




9. Spindle speed control analog voltage output




9.1 Interface Characteristics of voltage Output

Analog voltage output: **0-10V** output x1, **0-5V** output x1, optocoupler isolation.



9.2 Spindle Inverter Wiring






9.3 Configuration


9.3.1 Mach3's Spindle configuration, as shown below: (Config => Ports and Pins=> Spindle Setup)

Tick "Use Spindle Motor Output" and "PWM Control", type **4166** in "PWMBase Freq.", the unit is Hz.




Output signal configuration "Output Signals",
Set the corresponding "Output #1—Output #20"

9.3.2 Spindle relay configuration, as shown below: (Config => Ports and Pins=>Output Signals)




9.3.3 The phase configuration of the spindle speed control signal A10V/A5V is shown in the figure below:

(Config => Ports and Pins => Motor Outputs)



9.3.4 Mach3 menu "Config => Spindle Pulleys.", "Pulley Selection"




9.3.5 For other configurations of the spindle, please refer to "Mach3Mill_Install_Config.pdf"

9.3.6 Spindle test

In Diagnostics (Alt-7) or MDI(Alt-2):

- Keyboard input "M3".
- Keyboard input "S10000", spindle starts to rotate. (When testing, it is recommended to use half of the maximum speed to avoid the phase setting error and the spindle does not rotate. After the spindle is running, adjust the speed. Adjust the [spindle phase setting](#) when the spindle speed is opposite to the set speed)
- Keyboard input "M5", the spindle will stop rotating.




10. Slave axis (dual side motor drive: dual X/Y/Z)




10.1 Slave axis configuration

10.1.1 Slave axis requires board plug-in version 2.0.0.0 (or above), check the plug-in version first:



Right click on the CNC icon, pop up the settings dialog and the Title shows version ([plugin download](#))

10.1.2 Slave axis setting (Config => Slave Axis), the following example sets dual Y axis: A axis as slave.



10.1.3 Board' axis running direction is recommended as shown below: Mach3 menu => Config => Homing/Limits

Axis	Reversed	Soft Max	Soft Min	Slow ...	Home ...	Home Neg	Auto ...	Speed %
X	X	100.00	-100.00	1.00	0.0000	X	✓	20
Y	X	100.00	-100.00	1.00	0.0000	X	✓	20
Z	X	100.00	-100.00	1.00	0.0000	X	✓	20
A	X	100.00	-100.00	1.00	0.0000	X	✓	20
B	X	100.00	-100.00	1.00	0.0000	X	✓	20
C	X	100.00	-100.00	1.00	0.0000	X	✓	20

G28 home location coordinates

X: 0 A: 0
Y: 0 B: 0
Z: 0 C: 0

10.1.4 Mach3 tuning setup as shown below: (Config => Motor Tuning):

Y - AXIS MOTOR MOVEMENT PROFILE

Velocity mm's per Minute vs Time in Seconds

Axis Selection: X Axis, Y Axis, Z Axis, A Axis, B Axis, C Axis, Spindle

2 Steps per: 3200 Velocity: 1500 Acceleration: 100 G's: 0.050988

3 SAVE SAVE AXIS SETTINGS

A - AXIS MOTOR MOVEMENT PROFILE

Velocity mm's per Minute vs Time in Seconds

Axis Selection: X Axis, Y Axis, Z Axis, A Axis, B Axis, C Axis, Spindle


2 Steps per: 3200 Velocity: 1500 Acceleration: 100 G's: 0.203952

3 SAVE SAVE AXIS SETTINGS

The parameters must be exactly the same:
Steps per
Velocity
Acceleration

10.2 Single home switch configuration

10.2.1 Single Home Switch (Y axis) installation diagram



10.2.2 Only turn on the Y-axis Home Switch of Mach3.

(Config => Ports and Pins=>Input Signals)

Signal	Enabled	Port #	Pin Number	Active Low	Emulated	HotKey
Y ++	<input checked="" type="checkbox"/>	0	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
Y --	<input checked="" type="checkbox"/>	0	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
Y Home	<input checked="" type="checkbox"/>	1	2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
Z ++	<input checked="" type="checkbox"/>	0	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
Z --	<input checked="" type="checkbox"/>	0	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
Z Home	<input checked="" type="checkbox"/>	0	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
A ++	<input checked="" type="checkbox"/>	0	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
A --	<input checked="" type="checkbox"/>	0	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
A Home	<input checked="" type="checkbox"/>	0	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
B ++	<input checked="" type="checkbox"/>	0	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0

15 are inputs. Only these 5 pin numbers may be


Automated Setup of Inputs

确定 取消 应用(A)



10.3 Dual home switch (automatic leveling) configuration

10.3.1 Dual Home Switch (Y-axis and A-axis) installation diagram



10.3.2 Turn on the Y-axis and A-axis Home Switches of Mach3 at the same time.

(Config => Ports and Pins => Input Signals)

Engine Configuration... Ports & Pins

Signal	Enabled	Port #	Pin Number	Active Low	Emulated	HotKey
Y ++	<input checked="" type="checkbox"/>	0	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
Y --	<input checked="" type="checkbox"/>	0	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
Y Home	<input checked="" type="checkbox"/>	1	2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
Z ++	<input checked="" type="checkbox"/>	0	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
Z --	<input checked="" type="checkbox"/>	0	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
Z Home	<input checked="" type="checkbox"/>	0	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
A ++	<input checked="" type="checkbox"/>	0	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
A --	<input checked="" type="checkbox"/>	0	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
A Home	<input checked="" type="checkbox"/>	1	4	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
B ++	<input checked="" type="checkbox"/>	0	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0
-	<input checked="" type="checkbox"/>	0	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	0

Annotations:

- "Y Home" "v" Enable (points to Y Home Enabled checkbox)
- Port 1 (points to Y Home Port #)
- According to the actual wiring, Type 1-16 (points to Y Home Pin Number)
- NPN sensor is set to "v" (OV = active low) (points to Y Home Active Low checkbox)
- "A Home" "v" Enable (points to A Home Enabled checkbox)
- According to the actual wiring, Type 1-16 (Cannot be the same as Y Home) (points to A Home Pin Number)


Buttons: 确定, 取消, 应用 (A)

11. External Adjustment Knob




11.1 Interface characteristics of analog input

AIN1、 AIN2 analog input port: 0 - 3.3V, **non-isolated**



11.2 Wiring diagram

Connecting the adjustment-knob with the AIN1 of Motion board






11.3 Configuration

Start Mach3 and select the external motion board. Right click on the CNC machine icon, setting dialog will be shown. You can select one of the functions which is able to controlled by the external knob.

Please select "AIN1 -External" in your particular setting.



Then, click "OK" to exit.

Now, you can try to turn the knob to adjust your selected function.

