




Main circuit wiring

1. Single-phase power supply wiring:



2. Three-phase power supply wiring:



Note: When using the internal braking resistor, make short circuit of B2 and B3 (it has been factory connected); when using the external braking resistor, disconnect B2 and B3, and connect external braking resistor between B1 and B2.